SERAPHIN® GRADUATED DOUBLE NECK PROVER

OPERATING AND MAINTENANCE INSTRUCTIONS

Seraphin® Test Measure A Division of Pemberton Fabricators, Inc. Rancocas, NJ



JULY, 2004 SERIES K

2

NOTICE

PEMBERTON FABRICATORS, INC. (SERAPHIN® DIVISION) SHALL NOT BE LIABLE FOR TECHNICAL

OR EDITORIAL ERRORS IN THIS MANUAL OR OMISSIONS FROM THIS MANUAL. SERAPHIN $^{\tiny \odot}$ MAKES

NO WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF

MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE WITH RESPECT TO THIS MANUAL

AND, IN NO EVENT, SHALL SERAPHIN $^{\odot}$ BE LIABLE FOR ANY SPECIAL OR CONSEQUENTIAL

DAMAGES INCLUDING, BUT NOT LIMITED TO, LOSS OF PRODUCTION, LOSS OF PROFITS, ETC.

PRODUCT NAMES USED HEREIN ARE FOR MANUFACTURER OR SUPPLIER IDENTIFICATION ONLY

AND MAYBE TRADEMARKS/REGISTERED TRADEMARKS OF THESE COMPANIES.

THE CONTENTS OF THIS PUBLICATION ARE PRESENTED FOR INFORMATIONAL PURPOSES ONLY,

AND WHILE EVERY EFFORT HAS BEEN MADE TO ENSURE THEIR ACCURACY, THEY ARE NOT TO

BE CONSTRUED AS WARRANTTES OR GUARANTEES, EXPRESSED OR IMPLIED, REGARDING. THE

PRODUCTS OR SERVICES DESCRIBED HEREIN OR THEIR USE OR APPLICABILITY. WE RESERVE

THE RIGHT TO MODIFY OR IMPROVE THE DESIGNS OR SPECTFTCATIONS OF SUCH PRODUCTS AT

ANY TIME.

SERAPHIN® DOES NOT ASSUME RESPONSIBILITY FOR THE SELECTION, USE OR MAINTENANCE OF

ANY PRODUCT. RESPONSIBILITY FOR PROPER SELECTION, USE AND MAINTENANCE OF ANY

SERAPHIN® PRODUCT REMAINS SOLELY WITH THE PURCHASER AND END-USER.

SERAPHIN® IS THE REGISTERED TRADEMARK OF PEMBERTON FABRICATORS, INC

BY SERAPHIN® DIVISION of

PEMBERTON FABRICATORS, INC.

RANCOCAS, NJ, U.S.A.

No part of this work may be reproduced or copied in any form or

by any means – graphic, electronic or mechanical- without first

receiving the written permission or Pemberton Fabricators, Inc.

Seraphin® - 30 Indel Avenue – Rancocas, NJ 08073

CARE, MAINTENANCE, AND USE OF A SERAPHIN® PROVER

- A SERAPHIN[®] prover is designed and constructed according to NIST handbook 105-3 and API Manual of Petroleum Measurement Standards (MPMS) Chapter 4.
- Prover calibration may be established at 1-year intervals and extended or reduced on historical evidence up to the limit determined by your regulatory agency, but should not exceed 3 years due to possible leaking valves or seals which are often difficult to observe under field conditions.
- The prover should be maintained in a clean, dent free condition for accurate readings.

I. Prover Wetting Procedure:

1. If the prover is clean and free of debris, fill the prover bottom neck to the "0" zero mark with liquid from the meter device being checked.

NOTE: The prover must be filled once and drained in order to wet the internal sides of the prover body. Wetting the internals of the prover helps ensure consistency in the amount of liquid that clings to the sides, from one test to the next.

- 2. Reset the meter to "0" zero. Then fill the prover until the amount on the meter reads the nominal capacity of the prover.
- 3. This constitutes a "wet down" condition and is ready for an official test.

II. Testing Procedure:


1. Record the meter register, or zero the prover counter if one is being used.





WARNING: The prover system must be properly grounded prior to conducting petroleum measurement testing to prevent possible static electricity from sparking which could ignite a flammable product. Follow all safety measures.

- 2. Ensure the prover is grounded to a proper earth.
- 3. Verify that the prover drain valve is closed.
- 4. Select the proper fill method for which your prover is equipped:
 - Through the top of neck opening
 - Top Loading Bottom Fill Pipe (if supplied)
 - Bottom Loading Fill connection
 - Drybreak fitting
- 5. Make the connection from the petroleum dispenser to the appropriate fill fitting in which your prover is equipped.
- 6. Fill the prover bottom neck to the "0" zero mark, reset the meter to "0" zero. Then, fill the prover until the meter you are checking reads the nominal capacity of the prover.
- 7. Drain the Unit.
- 8. Redo Step # 5
- 9. Identify the volume measurement on the scale by reading the meniscus in the gauge glass. Look directly from eye level to a horizontal line tangential to the bottom of the meniscus. Record the result.



- 10. Drain the prover by opening the bottom drain valve. Once the main flow breaks, drain the prover for an additional 30 seconds and close the valve. This is necessary to provide a consistent "to deliver" condition.
- 11. Perform a second measurement by repeating the procedure in 3. through 6. above. Compare the meter reading to the volume observed on the scale. The two successive measurements should agree with the meter tolerance specifications of the meter manufacturer.



CAUTION: Disposal of drained fluid should be done in an environmentally safe and responsible manner in accordance with good industry practices and in compliance with OSHA regulations

12. If excessive disagreement is observed, check the dispenser and the prover for leakage and cleanliness and repeat the procedure until the results of two successive runs repeat within acceptable tolerance

III. Care and Maintenance

1. Check provers periodically for leaks at the valve, seams and at the gauge assembly. If a leak is detected, call your SERAPHIN® for authorized repair parts.

Note: Refer to NIST Handbook 44, API Manual of Petroleum Measurement Standards (MPMS) Chapter 4, Sect. 8 Operation of Proving Systems and Chapter 12.2 Calculations of Petroleum Quantities for detailed information and procedures.

Terminology

Bottom loading: Method of filling a volumetric vessel. Intake is made with a bottom load adapter.

Capacity, **nominal**: The nominal capacity of a field standard test measure or prover is the volume used to designate the measure or prover. The volume is determined by the nominal mark on a graduated upper neck gauge and between the nominal mark on the graduated upper neck gauge and the lower shut off valve or zero mark on a lower neck gauge on a prover.

NOTE: The nominal capacity of the prover has be set at the Seraphin[®] facility using Standards that are traceable to the National Institute of Standards and Technology (NIST). If uncertainty values or a higher order of calibration is needed the unit should be sent to a certified calibration laboratory.

Cubical coefficient of thermal expansion: Three dimensional expansion or contraction of a material due to temperature change, expressed °C⁻¹ or °F⁻¹

Field standard test measure: A measure that can be hand held and is usually less than 40 Liters (10 Gallons).

"High Resolution" standard: A standard with a small diameter neck for improved resolution in reading the meniscus. Generally used in the laboratory as a standard or check standard for measurement control of a primary standard.

Main flow cessation: The moment when a full discharge stream "breaks" and becomes a trickle or a drip.

Prover: Bottom drain is implied. Filled from the top or bottom loading, depending on intended use. May be free standing, mounted permanently, or on truck or trailer and not hand held.

Reference temperature: The temperature at which the measure is intended to contain or to deliver its nominal capacity.

Sight-flow-indicator: A fitting with windows to visually observe the flow through a pipe.

Submerged fill pipe: Pipe used in top filling to minimize foaming of liquids, such as fuel oil and milk, by discharging the product into the bottom of a prover.

To contain: An indication that the standard is adjusted to contain its intended volume when filled from its empty condition at a reference temperature. (the empty condition is "dry" and test measures or provers are generally not used in this condition).

To deliver: An indication that the standard is adjusted to deliver its intended volume at a reference temperature. Provers used in a "wet" condition are marked To Deliver.

Tolerance: Maximum permissible error. A value fixing the limit of allowable error or departure from the true performance or value.

Vapor recovery: A system for entrapping and collecting vapors for return to the tank to prevent expulsion into the atmosphere.

7

SAFETY

The use of a test measure or prover standard may involve hazardous materials,

operations, and equipment. Seraphin does not purport to address all safety problems

associated with the use of each product. It is the responsibility of the user of the

standard to establish appropriate safety and health practices and determine the

applicability of local and federal regulatory limitations prior to use. Specific safety

information is documented in the various trade references (e.g. American Petroleum

Institute and Petroleum Equipment Institute).

Commercial liquid measuring devices, tested with provers, are typically used to

measure quantities of petroleum products. Petroleum products are known hazardous

materials and hazardous wastes. The user is encouraged to obtain Material Safety Data

Sheets (MSDS) from the manufacturer of any product encountered. Federal, state and

local safety and disposal regulations concerning hazardous materials encountered

should be reviewed by the user.

Safety devices and locks should be installed to prevent inadvertent operation of, or

unauthorized tampering with, equipment. All automated or power-operated meter

proving systems should have emergency manual operators for use during an accident

or power failure. Grounding devices should be provided to protect against electrical

shock or static discharge in both tank prover and \ electrical instrumentation.

All electrical connections must be explosion proof. All wiring, including low voltage

wiring shall meet the requirements of Article 300, 500, Group D, Class 1, Division 1, and

250.45 and/or other applicable articles of the latest edition of the National Electrical

Code.

Seraphin® - 30 Indel Avenue – Rancocas, NJ 08073

8

SERAPHIN® TEST MEASURES

DIVISION OF PEMBERTON FABRICATORS, INC.

PO BOX 227 30 INDEL AVENUE

RANCOCAS, NJ 08073-0227

CERTIFICATE OF WARRANTY

PEMBERTON FABRICATORS, INC. FULLY WARRANTS THAT THE PRODUCT

SUPPLIED SHALL CONFORM TO THE DESCRIPTION IN THE QUOTATION AND

AGREES TO REPAIR OR REPLACE F.O.B. SHIPPING POINTS, ANY PARTS

EXCEPTING EXPENDABLE ITEMS SUCH AS FILTERS AND LIGHTS THAT FAIL

DUE TO DEFECTS IN MATERIAL OR WORKMANSHIP WITHIN ONE YEAR OF USE

OR 18 MONTHS AFTER SHIPMENT, WHICHEVER OCCURS FIRST.

Other than those expressively stated herein, there are no other warranties of any kind, expressed or

implied, and specifically excluded but not by way of limitation, are the implied warranties of

fitness for particular purpose and merchantability.

It is understood and agreed that Pemberton Fabricators, Inc.'s liability whether in contract, in tort,

under any warranty, in negligence or otherwise shall not exceed the cost of repair or replacement,

f.o.b. shipping points, of defective parts. Under no circumstances shall Pemberton Fabricators,

Inc. be liable for special, indirect, incidental, or consequential damages. The price stated for the

equipment is a consideration in limiting Pemberton Fabricators, Inc.'s liability. No action,

regardless of form, arising out of the transactions of this agreement may be brought by purchaser

more than one year after the cause of action has accrued.

The warranty for the equipment proposed is as stated in the above paragraphs. It is not

re-stated--nor does it appear in any other form.

Seraphin® - 30 Indel Avenue – Rancocas, NJ 08073